STANDARD DEPARTURE CHART INSTRUMENT (SID) - ICAO

TRANSITION ALT : **4000 '**
TRANSITION HGT : **(1180)**

ANAPA, RUSSIA
VITYAZEVO
RWY 21



ANAPA TOWER **119.800**
ANAPA RADAR **118.700**

WARNING:
1. Turn before passing DER is PROHIBITED.
2. For SID ARNAD 2D, GAMAN 2D, PALER 2D - pass DIST 25km from ARP at FL050 or above.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN ***FEET***
HEIGHTS IN METRES
ELEVATIONS IN ***FEET*** AND METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: New chart