STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

STAVROPOL, RUSSIA
SHPAKOVSKOYE
RNAV RWY 07



APPROACH	**121.050**
TOWER	**120.900**

❶ TRANSITION LEVEL:
- FL060 when QNH is 1013 hPa (760mm mercury column) or above;
- FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL080 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES IN *FEET* HEIGHTS IN METRES ELEVATIONS IN *FEET* AND METRES DISTANCES IN KILOMETRES	Alt set: - QNH (QFE on req); - hPa (mm on req).

CHANGE: Limiting bearing line withdrawn, URP705, URP713, URP739