INSTRUMENT APPROACH CHART - ICAO

VNUKOVO TOWER	**118.300**
VNUKOVO RADAR	**123.400 126.000 135.900**

MOSCOW, RUSSIA
VNUKOVO
RNP RWY 06

TRANSITION LEVEL: ❶	TRANSITION ALT: *10000 '*	AD ELEV:	***685 '/209m***
	TRANSITION HGT: (2900)	THR ELEV:	***629 '/191.5m***

DIST to RW06	6.0	4.0	2.0
ALT/HGT	*1710 '/(330)*	*1370 '/(230)*	*1020 '/(120)*

MISSED APPROACH
Climb straight ahead to WW652, turn RIGHT to WW187 climbing to *3500 '/(880)*, then proceed to NDB LO-BEMAS--TEBDI-TEPTA-SIDAZ-NDB DR-RORUK or by ATC instruction.

OCA(H)		A	B	C	D
Straight-in Approach	**LNAV**	*1000 '(370 ')/(115)*	*1000 '(370 ')/(115)*	*1000 '(370 ')/(115)*	*1000 '(370 ')/(115)*
	LNAV/VNAV	*950 '(321 ')/(98)*	*963 '(334 ')/(102)*	*971 '(342 ')/(105)*	*981 '(352 ')/(108)*

❶ TRANSITION LEVEL:
- FL110 when QNH is 1013 hPa (760mm mercury column) or above;
- FL120 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL130 when QNH is less than 977 hPa (733mm mercury column).

GROUND SPEED	km/h	*150*	*180*	*210*	*240*	*270*	*300*	*330*	*360*	*390*	*420*	*450*
RATE OF DESCENT	m/s	*2.2*	*2.6*	*3.0*	*3.5*	*3.9*	*4.3*	*4.8*	*5.2*	*5.6*	*6.1*	*6.5*
	ft/min	*427*	*512*	*597*	*682*	*768*	*853*	*938*	*1024*	*1109*	*1194*	*1280*

CHANGE: UUP