STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL: ❶

SANKT-PETERBURG, RUSSIA
PULKOVO
RNAV RWY 28R, 28L



APPROACH	Sector 1	(EAST)	H24	**119.300**
	Sector 2	(WEST)	0600-1600	**125.200**
	Sector 2	(WEST)	1600-0600	**119.300**
RADAR			H24	**120.300**
TOWER	RWY 10L/28R		H24	**118.100**
TOWER	RWY 10R/28L		H24	**118.700**

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN ***FEET***
HEIGHTS IN METRES
ELEVATIONS IN ***FEET***
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

❶ TRANSITION LEVEL:
- FL050 when QNH is 996 hPa (747mm mercury column) or above;
- FL060 when QNH is 960 hPa (720mm mercury column) or above, but less than 996 hPa (747mm mercury column);
- FL070 when QNH is less than 960 hPa (720mm mercury column).

NOTE:
1. Descent shall be carried out only by ATS unit instruction.
2. The flight crews shall advise ATS unit if unable to adhere to altitude (flight level) or speed restrictions.

CHANGE: ULP49, ULP50