VISUAL APPROACH CHART - ICAO

VLADIVOSTOK RADAR	123.400
VLADIVOSTOK START	119.500

VLADIVOSTOK, RUSSIA
KNEVICHI
RWY 07R/25L

TRANSITION LEVEL: ❶

AD ELEV: 59 '/18m



❷ UHP339
100m/400'AGL
GND

❸ UHP349
150m/500'AGL
GND

❹ UHP348
150m/500'AGL
GND

❺ UHP335
450m/1500'AMSL
GND

❶ TRANSITION LEVEL:
- FL090 when QNH is 1013 hPa (760mm mercury column) or above;
- FL100 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL110 when QNH is less than 977 hPa (733mm mercury column).

Alt set: -QNH (QFE on req);
-hPa(mm on req).

CHANGE: New chart