VFR ARRIVAL CHART

TRANSITION LEVEL: ❶

YAKUTSK, RUSSIA
YAKUTSK
RWY 05



APPROACH	**129.300**
RADAR	**120.300**
START	**120.000**

❶ TRANSITION LEVEL:
- FL050 when QFE is 751mm mercury column or above;
- FL060 when QFE is 724mm mercury column or above, but less than 751mm mercury column;
- FL070 when QFE is less than 724mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN METRES AND ***FEET***
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);
-mm(hPa on req).

CHANGE: New chart