STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

VLADIVOSTOK, RUSSIA
KNEVICHI
RWY 25L



VLADIVOSTOK RADAR **123.400**
VLADIVOSTOK START **119.500**

❶ TRANSITION LEVEL:
- FL090 when QNH is 1013 hPa (760mm mercury column) or above;
- FL100 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL110 when QNH is less than 977 hPa (733mm mercury column).

NOTE
Holding procedure shall be executed by arrangement with ATS unit, when one of the areas UHR1452, UHR1479, UHR1480, UHR1498 is active.

BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES IN *FEET* HEIGHTS IN METRES ELEVATIONS IN *FEET* AND METRES DISTANCES IN KILOMETRES	Alt set: -QNH(QFE on req); -hPa(mm on req).

CHANGE: New chart