STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

NOVOSIBIRSK, RUSSIA
TOLMACHEVO
RWY 34



APPROACH	**127.500**
RADAR	**122.000**
TOWER	**126.700**

❶ TRANSITION LEVEL:
- FL070 when QNH is 1013 hPa (760mm mercury column) or above;
- FL080 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL090 when QNH is less than 977 hPa (733mm mercury column).

WARNING
Holding area shall be used, if clearance to cross UNR1187 (during its activity) or arrangement with ATS unit are AVBL.

NOTE
TAR distance is indicated from VORDME.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN *FEET*, HEIGHTS IN METRES
ELEVATIONS IN METRES AND *FEET*
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: UNP379