STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❷

ULYANOVSK, RUSSIA
VOSTOCHNY
RWY 02



VOSTOCHNY TOWER **124.200**

❷ TRANSITION LEVEL:
- FL050 when QNH is 977 hPa (733mm mercury column) or above;
- FL060 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES IN *FEET* ELEVATIONS IN *FEET* AND METRES HEIGHTS IN METRES DISTANCES IN KILOMETRES	Alt set: - QNH (QFE on req); - hPa (mm on req).

CHANGE: HGT