

**EDTY AD 2.17 ATS airspace**

1	Designation and lateral limits	RMZ
2	Vertical limits	1000 ft AGL
3	Airspace classification	G
4	ATS unit call sign Language(s)	SCHWAEBISCH HALL INFORMATION English, German
5	Transition altitude	5000 ft MSL
6	Hours of applicability	NIL
7	Remarks	For detailed airspace description see ENR 2.2

**EDTY AD 2.18 ATS communication facilities**

Service designation	Call sign	Channel/ Frequency (MHZ)	Sat- voice	Logon address	Hours of operation	Remarks
1	2	3	4	5	6	7
ATIS	SCHWAEBISCH HALL ATIS	133.880	-	-	H24	Designated operational coverage 40 NM , FL 150
APP	LANGEN RADAR	125.050	-	-	H24	
AFIS	SCHWAEBISCH HALL INFORMATION	129.230	-	-	Mon – Fri 0600 (0500) – 1900 (1800) 1 APR – 30 SEP: Sat, Sun, HOL 0700 – 1800 1 OCT – 31 MAR: Sat, Sun, HOL 0800 (0700) – 1700 (1600) Other times: PPR	Designated operational coverage 25 NM, 4000 ft AGL
TWR	SCHWAEBISCH HALL DEICING	121.755	-	-	HX	Only during winter operation.

**EDTY AD 2.19 Radio navigation and landing aids**

Type of aid MAG VAR Type of supported OPS VOR/ILS/MLS declination	ID	Frequency/ Channel service provider RPI	Hours of operation	Position of transmitting antenna coordinates	Elevation of DME transmitting antenna	Service volume radius GBAS	Remarks
1	2	3	4	5	6	7	8
<b>Dinkelsbuehl</b> DVOR/DME (2° E/2012)	DKB	117.80 MHz CH125x	H24	N 49 08 33.91 E 010 14 17.90	1769	-	Operational coverage sector 0°–360°: 60 NM, 50000 ft MSL The DVOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation. Radial 136 is not usable from 14 NM to 22 NM between 5000 ft and 6000 ft. In addition, the DME can be used for the published procedures. DME unusable in sector 0°–360°: below 0 – 10 NM 2900 ft MSL 10 – 20 NM 4100 ft MSL 20 – 30 NM 5500 ft MSL 30 – 40 NM 7000 ft MSL 40 – 50 NM 8700 ft MSL 50 – 60 NM 10500 ft MSL