

WAY POINT LIST

DUESSELDORF

GPS/FMS RNAV TRANSITION TO FINAL APPROACH (OVERLAY TO RADAR VECTOR PATTERN)					
Route Description					
RWY assignment valid for lost COM situation only. During normal operations both RWYs will be used.					
CODING				DISPLAY	
PISAP 05					
PISAP	F170-	N 51 47 38.47	E 006 38 25.47	N 51 47.6	E 006 38.4
VALSU	R	N 51 28 05.00	E 006 45 28.00	N 51 28.1	E 006 45.5
GAPNU	K220; R	N 51 22 44.13	E 006 44 27.11	N 51 22.7	E 006 44.5
DL524		N 51 15 27.57	E 006 29 14.39	N 51 15.5	E 006 29.2
DL530	K220	N 51 10 35.44	E 006 19 08.60	N 51 10.6	E 006 19.1
DIKMI	A3000+	N 51 11 43.59	E 006 33 51.45	N 51 11.7	E 006 33.9
FINAL APPROACH 05L [ILS - LOC - RNP]					
HALME 05					
HALME	F140-	N 51 42 19.00	E 007 12 00.00	N 51 42.3	E 007 12.0
BOMBA	R	N 51 33 06.00	E 007 06 25.00	N 51 33.1	E 007 06.4
DL524		N 51 15 27.57	E 006 29 14.39	N 51 15.5	E 006 29.2
DL530	K220	N 51 10 35.44	E 006 19 08.60	N 51 10.6	E 006 19.1
DIKMI	A3000+	N 51 11 43.59	E 006 33 51.45	N 51 11.7	E 006 33.9
FINAL APPROACH 05L [ILS - LOC - RNP]					
DOMUX 05					
DOMUX	F140-	N 51 25 11.46	E 007 32 10.88	N 51 25.2	E 007 32.2
DOLAV	L	N 51 25 18.00	E 007 10 19.00	N 51 25.3	E 007 10.3
DL502	K220; R	N 51 12 21.60	E 006 49 01.01	N 51 12.4	E 006 49.0
DL503		N 51 09 56.50	E 006 43 57.14	N 51 09.9	E 006 44.0
DL510	K220	N 51 02 39.90	E 006 28 48.74	N 51 02.7	E 006 28.8
NATOS	A3000+	N 51 11 29.48	E 006 34 04.52	N 51 11.5	E 006 34.1
FINAL APPROACH 05R [ILS - LOC - RNP]					
ELDAR 05					
ELDAR	F170-	N 51 01 23.00	E 006 40 46.00	N 51 01.4	E 006 40.8
DL501	K220; L	N 51 08 22.68	E 006 53 49.09	N 51 08.4	E 006 53.8
DL502	K220; L	N 51 12 21.60	E 006 49 01.01	N 51 12.4	E 006 49.0
DL503		N 51 09 56.50	E 006 43 57.14	N 51 09.9	E 006 44.0
DL510	K220	N 51 02 39.90	E 006 28 48.74	N 51 02.7	E 006 28.8
NATOS	A3000+	N 51 11 29.48	E 006 34 04.52	N 51 11.5	E 006 34.1
FINAL APPROACH 05R [ILS - LOC - RNP]					