

Type of aid MAG VAR Type of supported OPS VOR/ILS/MLS <i>declination</i>	ID	Frequency/ Channel service provider RPI	Hours of operation	Position of transmitting antenna/ GBAS reference point coordinates	Elevation of DME transmitting antenna/ elevation GBAS reference point	Service volume radius from GBAS- reference point (NM)	Remarks
1	2	3	4	5	6	7	8
Nienburg DVOR/DME (4° E/2024)	NIE	109.25 MHz CH29y	H24	N 52 37 33.03 E 009 22 19.74	191	-	Operational coverage sector 0°–360°: 60 NM, 50000 ft MSL The DVOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation. In addition, the DME can be used for the published procedures. DME unusable in sector 0°–240°: below 0 – 10 NM 1400 ft MSL 10 – 20 NM 2800 ft MSL 20 – 30 NM 4300 ft MSL 30 – 40 NM 6000 ft MSL 40 – 50 NM 7800 ft MSL 50 – 60 NM 9700 ft MSL DME unusable in sector 240°–360°: below 0 – 10 NM 2200 ft MSL 10 – 20 NM 4400 ft MSL 20 – 30 NM 6700 ft MSL 30 – 40 NM 9100 ft MSL 40 – 50 NM 11700 ft MSL 50 – 60 NM 14400 ft MSL
Weser NDB	WSN	378.00 KHz	H24	N 53 20 49.81 E 008 52 29.04		-	Operational range sector 0°–360°: 60 NM NDB unusable: in sector from station 318°–323° 53 NM 323°–318° 60 NM