


INSTRUMENT
APPROACH
CHART - ICAO

SIVKAR RADAR 124.600

SYKTYVKAR, RUSSIA
SYKTYVKAR
ILS Z CAT I RWY 18




②	CAT A	352°	3min 30sec
	CAT B	351°	3min
	CAT C	335°	2min
	CAT D	325°	1min 30sec

⑤	CAT A	3min 30sec
	CAT B	3min
	CAT C	2min
	CAT D	1min 30sec

Alt set: - QNH (QFE on req);
- hPa (mm on req).

BEARINGS AND TRACKS ARE MAG.
ELEV IN FEET AND METRES
ALT IN FEET
HGT IN METRES
DISTANCES IN KILOMETRES



OCA(H)		A	B	C	D						
Straight-in Approach	CAT I	458' (148') (46)	469' (159') (49)	481' (171') (53)	492' (182') (56)						
	Circling	790' (450') (140)	840' (510') (155)	940' (600') (185)	1030' (700') (215)						
GROUND SPEED	km/h	150	180	210	240	270	300	330	360		
	kt	81	97	113	130	146	162	178	194		
RATE OF DESCENT	m/s	2.2	2.6	3.0	3.5	3.9	4.3	4.8	5.2		
	ft/min	427	512	597	682	768	853	938	1024		

① **TRANSITION LEVEL:**
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).

WARNING:
1. Visual manoeuvring west of the aerodrome is PROHIBITED.
2. DME ISR reads zero at RWY 18 THR.

CHANGE: MNM