

Type of aid MAG VAR Type of supported OPS VOR/ILS/MLS declination	ID	Frequency/ Channel service provider RPI	Hours of operation	Position of transmitting antenna coordinates	Elevation of DME transmitting antenna	Service volume radius GBAS	Remarks
1	2	3	4	5	6	7	8
<b>Karlsruhe/Baden-Baden</b>							
NDB	KBA	431.00 KHz	H24	N 48 47 52.68 E 008 05 51.19		-	Operational range sector 0°–360°: 30 NM NDB unusable: in sector from station <hr/> 050°–310° 30 NM 310°–050° 15 NM
<b>Stuttgart</b>							
DVOR/DME (2° E/2012)	STG	116.85 MHz CH115y	H24	N 48 41 47.14 E 009 15 23.57	1207	-	Operational coverage sector 0°–360°: 60 NM, 50000 ft MSL The DVOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation. DME unusable in sector 0°–360°: below <hr/> 0 – 10 NM 2300 ft MSL 10 – 20 NM 3600 ft MSL 20 – 30 NM 4900 ft MSL 30 – 40 NM 6500 ft MSL 40 – 50 NM 8100 ft MSL 50 – 60 NM 9900 ft MSL
<b>Sulz</b>							
DVOR (2° E/2012)	SUL	116.10 MHz	H24	N 48 22 53.71 E 008 38 41.41		-	Operational coverage sector 0°–360°: 60 NM, FL 250 The DVOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation.