

STANDARD ARRIVAL CHART-INSTRUMENT


RJTH/HACHIOJIMA RNAV STAR RWY26

SANGO ARRIVAL

RNP1

Note GNSS required.

VAR7°W



SANGO
332250.4N
1394814.0E
5000



9.5
134°




TH671
331705.1N
1395719.0E

6.0
164°



SHELL
331133.7N
1400008.6E
2000



CHANGE : Navigation Specification(Basic RNP1 → RNP1).

From SANGO at or above 5000FT, to TH671, to SHELL at or above 2000FT.

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	SANGO	-	-	-6.9	-	-	+5000	-	-	RNP1
002	TF	TH671	-	134 (127.1)	-6.9	9.5	-	-	-	-	RNP1
003	TF	SHELL	-	164 (156.8)	-6.9	6.0	-	+2000	-	-	RNP1

Path	Waypoint Identifier	Inbound Course °M(°T)	Magnetic Variation	Outbound Time (MIN)	Turn Direction	Minimum Altitude (FT)	Maximum Altitude (FT)	Speed (KIAS)	Navigation Specification
Hold	SANGO	190 (182.8)	-6.9	1.0(-14000)	R	5000	FL140	-230(-14000)	RNP1

INTENTIONALLY LEFT BLANK